# ELECTRIC BUILDERS BOX USER'S GUIDE

# **MODEL NUMBERS:**

36EB110-GRT, 36EB111-GRC 36EB220-GRT, 36EB221-GRC

### **CONSUMER SAFETY INFORMATION**

PLEASE READ THIS MANUAL BEFORE USING THIS APPLIANCE WARNING

IF THE INFORMATION IN THIS MANUAL IS NOT FOLLOWED, AN ELECTRIC SHOCK OR FIRE MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.

DO NOT STORE OR USE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE.

Thank you and congratulations on your purchase of a Classic Flame electric builder box. Please read the installation instructions before installing and operating this appliance.

**IMPORTANT:** Read all instructions and warnings carefully before using. Failure to follow these instructions may result in a possible electric shock, fire hazard and/ or injury and will void the warranty.

### **For Customer Service:**

www.tsicustomerservice.com 866-661-1218 Twin-Star International, Inc.

Delray Beach, FL 33445

U.S.A.

Made in China

Printed in China

©2013, Twin-Star International,Inc.



## IMPORTANT INSTRUCTIONS


Please read and understand this entire manual before attempting to assemble, operate or install the product.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electrical shock, and injury to persons including the following:


- 1. Read all instructions before using this appliance.
- 2. The appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- 3. Any repairs to this builder box should be carried out by a qualified service person.
- 4. Do not use outdoors.
- 5. To cut the power to the unit, turn the on/off on the wall mounted controls to the off position.
- 6. This appliance, when installed, must be electrically grounded in accordance with local codes or, in the absence of local codes, with the current CSA C22.1 Canadian Electrical Code or for U.S.A. installations, follow local codes and the National Electrical Code, ANSI/NFPA NO.70.
- 7. This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this appliance. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 m) from the front of this appliance. **WARNING: In order to avoid overheating, do not cover the heater. It cannot be used in a closet.**
- 8. There is a thermostat limiter inside the heater. When the inner temperature over heating or occurs abnormal heating, the thermostat protective device would cut off power supply to avoid the fireplace damaged or risk of fire.
- 9. The heaters must not be located immediately below a socket-outlet.
- 10. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where opening may become blocked.
- 11. Use this appliance only as described in the manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.

### SAVE THESE INSTRUCTIONS

### PRODUCT ORIENTATION



# PRODUCT ORIENTATION



PARTS LIST		
Part Name	36EB110-GRT 36EB220-GRT	36EB111-GRC 36EB221-GRC
Logs	✓	
Stones		✓
Heater	✓	✓
Blower Assembly	✓	✓
Main Power Switch	✓	✓
Main PCBA	✓	✓
Flame PCBA	✓	✓
Front Projection Screen	✓	✓
Flame Generator Drive Motor	✓	✓
Flame Generator/Spinner	✓	✓
Remote Control - 6 Buttons	✓	
Remote Control - 8 Buttons		✓
Control Box - 7 Buttons	✓	
Control Box - 9 Buttons		✓

### **OPERATION**

The builders box can be operated by the wall mounted control box or remote control.

### **CONTROL FUNCTIONS**

**Note:** Make sure the Main Power Switch is in the ON position to operate the unit (Figure 3).

### **POWER**

The power button will put the insert in standby mode. This will turn off all functions and hold the settings in memory; pressing the button again will turn on the unit to the previous setting.

### COLOR (FLAME)

Changes the flame effect color. There are 3 color setting available: orange, blue, orange and blue.

### **LEVEL (FLAME)**

Changes the brightness of the flame effect. There are 5 brightness levels you can cycle through and the OFF setting.

**UP (FLAME)** (For model 36EB110-GRT & 36EB220-GRT) Increases the flame intensity. There are 5 brightness levels and OFF.

**DOWN (FLAME)** (For model 36EB110-GRT & 36EB220-GRT) Decreases the flame intensity. There are 5 brightness levels and OFF.

### **HEAT**

Turns the heater on and off. The LED indicator light besides the heat button will light up when on.

**NOTE**: Holding the POWER button on the control panel for 10 second will disable the heater function. To re-enable the heater press and the hold the POWER button for 10 seconds.

### **TEMPERATURE DISPLAY**

Displays the current ambient temperature, operational range  $60^{\circ}F$  -  $90^{\circ}F$ .

### **TIMER**

There are 10 timer setting (OFF -30 minutes - 1 hour - 2H-3H-4H-5H-6H-7H-8H-9H) pressing the timer button will cycle through the settings.

### **UP (LIGHT EFFECTS)**

Pressing this button will change the uplight between the 6 settings: white, red, green/red/green/blue, green/blue, white/blue/red, blue and OFF.

### DOWN (LIGHT EFFECTS)

Pressing this button will change the downlight between 6 settings: white, red, green/red/green/blue, green/blue, white/blue/red, blue and OFF.

### **AUTO (LIGHT EFFECTS)**


Turns on/off automatic cycling for the downlights and uplights.


### **EMBERS**


Turns on/off undulating emberbed effect.

### **THERMOSTAT**

The themostat sets the heater cut off level.







NOTE: PLEASE OPERATE REMOTE TRANSMITTER
AT A SLOW MEASURED PACE. PRESS THE
REMOTE CONTROL BUTTONS WITH AN EVEN
MOTION AND GENTLE PRESSURE. REPEATEDLY
PRESSING BUTTONS IN RAPID SUCCESSION
MAY CAUSE THE TRANSMITTER TO MALFUNCTION.

**Note:** When a function is changed from the control panel or remote control there will be a corresponding indicator (see Figure 7) on the upper-right of the projection screen. The indicator shows the function changed and the level selected by the control panel or remote control. When the function is turned off, the corresponding indicator will flash 5 times and then fade off.

# Figure 6: Remote Control 36EB111-GRC 36EB221-GRC 36EB110-GRT 36EB220-GRT FLAME LEVEL CYCLE FLAME EMBERS FLAME EMBERS FLAME FLAME EMBERS FLAME FLAME

### REPLACING THE REMOTE CONTROL BATTERY


When the remote control stops operating or its range seems reduced, it is time to replace the battery with a new one.

- 1. The battery compartment is located on the back end of the remote.
- 2. Press and slide the battery door open and remove the old battery.
- 3. Insert 2pcs AAA batteries, checking that the + and sides of the battery match inside the battery compartment.
- 4. Replace the battery compartment door.

NOTE: Do not mix old and new batteries.

Do not mix alkaline, standard (carbon zinc), or rechargeable (nicad, nimh, etc.) batteries.

Do not ingest.



### **DISPOSAL OF USED BATTERIES**

Battery may contain hazardous substances which could endanger the environment and human health.



This symbol marked on the battery and/ or packaging indicates that used battery shall not be treated as municipal waste. Batteries should be disposed of at an appropriate collection point for recycling.

By ensuring the used batteries are disposed of correctly, you will help prevent potential negative consequences for the environment and human health. The recycling of materials will help to converse natural resources.

For more information about recycling of used batteries, please contact your local municipality waste disposal service.



As an important safety feature, the heating element is designed with a delayed activation sequence. Therefore, when the heater is turned ON it will take several minutes for the unit to begin blowing hot air. Subsequently, the fan blower will continue to run for several minutes after the heater is switched OFF.

If heater doesn't work, but Power and Heater switches are in the "ON" position and thermostat is set on "HI", the product is on the protected status, then turn all switches to the "OFF" position and unplug the unit from the wall outlet for 30 minutes. After 30 minutes plug the unit back into wall outlet, and operate as normal.

# TWO YEAR LIMITED WARRANTY (PROFESSIONALLY INSTALLED AND/OR BUILT IN ELECTRIC INSERTS)

Twin-Star International, Inc. (the "Company") warrants to the original purchaser of a new professionally installed and/or built in ClassicFlame Electric Fireplace Insert (the "Fireplace Insert") is free from manufacturing defects in materials and workmanship for a period of two (2) years from the date of original retail purchase from a qualified/authorized Twin-Star dealer, subject to the following terms, conditions and limitations. This warranty is for the USA and Canada only.

# I. What this limited warranty covers and for how long

The Company warrants the Fireplace Insert to be free from defects in material and workmanship for a period of two (2) years from the date of original retail purchase, as follows: replacement of defective products or parts (with no in-home services) as further described in Part IV below.

### II. What this limited warranty does not cover

This limited warranty does not apply to

- (a) replacement of Fireplace Insert light bulbs,
- (b) Fireplace Insert components that have been repaired (except by the Company or its authorized service representatives) or otherwise altered or modified,
- (c) damage, malfunction or defects resulting from shipping or transit, misuse, abuse, accident, neglect, incorrect installation, improper maintenance or handling, or operation with an incorrect power source,
- (d) damage from fire, water, lightning, power surges, abnormal environmental conditions or other acts of nature, and
- (e) normal wear and tear.

The Company reserves the right to assess all warranty claims and to determine if the claimed defects or damages are covered by this limited warranty. This limited warranty applies only to the original purchaser of the Fireplace Insert from a qualified/authorized Twin-Star dealer in the USA or Canada, and is not transferable.

# III. What you must do to get service under this limited warranty

For warranty service, please contact the Company by

phone at 1-866-661-1218, or by mail at 1690 S. Congress Ave., Suite 210, Delray Beach, FL 33445, USA. Please have proof of purchase, catalogue/model, manufacturer's date code and serial numbers available when calling. Proof of purchase showing the original purchase date and location is required to obtain warranty service.

# IV. What the Company will do in the event of a covered warranty claim

For valid warranty claims made prior to the second anniversary of the date of original retail purchase, the Company will elect in its sole discretion to either repair or replace the covered defective product or part without charge. If the Company is unable to repair or replace the covered defective product or part, or if repair or replacement is not c ommercially practicable or cannot be timely made, the Company may elect in its sole discretion, in lieu of replacement, to refund the purchase price for the defective product or part. Warranty services under this paragraph do not include on-site or in-home warranty services, and you will be solely responsible for all expenses incurred for the removal of the defective product or part and installation of the replacement product or part, including, without limitation, all labor costs and all shipping and transportation costs to and from the Company and/or its authorized dealer or service agent.

All warranty services will be performed solely by the Company's authorized dealers or service agents. On-site or in-home services not covered by this limited warranty may be performed at your specific request and expense, at the Company's customary rates for such services.

# V. DISCLAIMER OF WARRANTIES AND LIABILITY LIMITATIONS

THERE ARE NO EXPRESS WARRANTIES MADE BY THE COMPANY OTHER THAN THOSE LIMITED WARRANTIES DESCRIBED ABOVE. THE COMPANY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT ANY APPLICABLE JURISDICTION PROHIBITS DISCLAIMER OF IMPLIED WARRANTIES, SUCH IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO THE APPLICABLE PERIODS OF TIME SET FORTH IN THE EXPRESS LIMITED WARRANTIES DESCRIBED ABOVE.

IN NO EVENT WILL THE COMPANY, OR ANY OF ITS DIRECTORS, OFFICERS OR AGENTS, BE LIABLE TO ANY PURCHASER, OWNER, OR USER OF THE FIREPLACE INSERT, OR TO ANY THIRD PARTY, WHETHER IN CONTRACT, IN TORT, OR ON ANY OTHER BASIS, FOR ANY INDIRECT, SPECIAL, PUNITIVE, EXEMPLARY, CONSEQUENTIAL, OR INCIDENTAL LOSS, COST, OR DAMAGE ARISING OUT OF OR IN CONNECTION WITH THE SALE, MAINTENANCE, USE, OR INABILITY TO USE THE FIREPLACE INSERT, EVEN IF THE COMPANY OR ITS DIRECTORS, OFFICERS OR AGENTS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSSES, COSTS OR DAMAGES, OR IF SUCH LOSSES, COSTS, OR DAMAGES ARE FORESEEABLE. IN NO EVENT WILL THE COMPANY, OR ANY OF ITS DIRECTORS, OFFICERS OR AGENTS, BE LIABLE FOR ANY DIRECT LOSSES, COSTS, OR DAMAGES THAT EXCEED THE PURCHASE PRICE OF THE FIREPLACE INSERT. SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS

ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU

ANY AND ALL SERVICE OR REPAIR WORK DEEMED NECESSARY MUST BE PERFORMED BY A REPAIR SPECIALIST. DO NOT ATTEMPT TO DO ANY SERVICE OR REPAIR WORK YOURSELF. IMPROPER SERVICE OR REPAIR MAY RESULT IN PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

This limited warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction. The provisions of the United Nations Convention on Contracts for the Sale of Goods shall not apply to this limited warranty or the sale of products covered by this limited warranty.

RESULT IN PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

# For product warranty registration please visit: www.tsicustomerservice.com/registration

Before setting up this product please record the model number and serial number of this product in the spaces below for in registration and warranty reference.

<b>Model Number</b>	Serial Number

Twin-Star International, Inc. Delray Beach, FL 33445 Made in China Printed in China

© 2013, Twin-Star International, Inc.